



**FITTING INSTRUCTIONS FOR BLP0031BK REAR FOOTREST BLANKING
PLATE
YAMAHA MT-09 2013-**



Please note that the way the kit is packed does not necessarily represent the way of mounting to the bike

THE PARTS SHOWN MAY BE REPRESENTATIVE ONLY (FOR CLARITY OF INSTRUCTIONS ONLY)

Please note that in cases where kits are packed with rubber washers holding the components onto the bolt – *the rubber washers should be thrown away!*

TOOLS REQUIRED

- 3, 6 & 8mm A/F Allen key.
- 8mm spanner or socket & wrench.



Picture 1



Picture 2



Picture 3



Picture 4

FITTING INSTRUCTIONS

- Remove rear pillion footrest from both sides of the bike.
- On the right hand pillion footrest, remove the bracket that mounts the brake reservoir by removing the 8mm nut.
- Fit two counter-sunk head bolts through the holes in each of the blanking plates.
- On the left side of the bike, the blanking plate bolts straight into place.
- On the right side of the bike, the blanking plate fits in front of the mounting bracket which supports the brake reservoir, as shown in picture 1.
- This can now be fitted to the bike, as shown in picture 2.
- Locate the M5 x 20mm long button head bolt through the small hole on the brake reservoir mount, then through the brake reservoir rubber mount, before fitting the M5 washer and nyloc nut on the rear, as shown in pictures 4 & 5, before tightening.
- Tighten all bolts evenly.

ISSUE 1 16/10/2013 (AR)

CONSUMER NOTICE

The catalogue description and any exhibition of samples are only broad indications of the Products and R&G may make design changes which do not diminish their performance or visual appeal and supplying them in such state shall conform to the order. The Buyer acknowledges no representation or warranty (other than as to title) has been given or will apply to the Products other than those in R&G's order or confirmation and the Buyer confirms it has chosen the Products as being of merchantable quality and suitable for its particular purposes. Where R&G fits the Products or undertakes other services it shall exercise reasonable skill and care and rectify

R&G Racing
Unit 1, Shelley's Lane, East Worldham, Alton, Hampshire, GU34 3AQ
Tel: +44 (0)1420 89007 Fax: +44 (0)1420 87301 www.rg-racing.com Email: info@rg-racing.com



any fault free of charge unless the workmanship has been disturbed. The Buyer is responsible for ensuring that the warranty on the motorcycle is not affected by the fitting of the Products. On return of any defective Products R&G shall at its option either supply a replacement or refund the purchase money but shall not be liable if the Products have been modified or used or maintained otherwise than in accordance with R&G's or manufacturer's instructions and good engineering practice or if the defect arises from accident or neglect. Other than identified above and subject to R&G not limiting its liability for causing death and personal injury, it shall not be liable for indirect or consequential loss and otherwise its liability shall be limited to the amounts paid by the Buyer for the Products or the fitting or service concerned. These terms do not affect the Buyer's statutory rights.

R&G RACING RETURNS POLICY (NON-FAULTY GOODS)

Returns must be pre-authorized (if not pre-authorized the return will be rejected). Goods may only be returned direct to us if they were purchased direct from us (customer must prove if necessary). Otherwise to be returned to original vendor. Goods must be in re-sellable condition, in the opinion of R&G Racing. All returns are subject to a 25% restocking and handling fee (25% of the gross value exc. P&P – at the prevailing price at time of purchase). The customer must pay any and all carriage charges. No returns of discontinued products, unless within 14 days of purchase. This policy does not affect your statutory rights and does not refer to faulty goods.



INSRUCTIONS DE MONTAGE POUR BLP0031BK PROTECTION REPOSE
PIED
YAMAHA MT-09 2013-



LA FAÇON DONT LE KIT EST EMBALLE NE CORRESPOND PAS FORCEMENT A LA FAÇON DE MONTER LES PIECES SUR LA MOTO.

LES PARTIES PRESENTEES PEUVENT ETRE UNIQUEMENT REPRESENTATIVES (POUR LA CLARTE DES INSTRUCTIONS UNIQUEMENT)

Notez que si les kits sont emballés avec des rondelles en caoutchouc servant à tenir les composants, *ces rondelles doivent être jetées.*

OUTILS REQUIS

- Clés Allen 3, 6 & 8mm.
- Clé ou douille de 8mm.



Photo 1



Photo 2



Photo 3



Photo 4

Instructions de montage :

- Enlever le repose pied de chaque coté de la moto.
- Sur le repose pied passage coté droit, enlever le support qui fixe le réservoir liquide de frein en enlevant l'écrou 8mm.
- Installer 2 boulons dans les trous de chaque plaque de protection R&G.
- Du coté gauche de la moto, les boulons de plaque de protection sont maintenus bien en place.
- Du coté droit de la moto, la plaque de protection R&G de place à l'avant du support de fixation qui fixe le réservoir de liquide de frein (Photo 1).
- Il peut à présent être installé sur la moto (Photo 2).
- Placer le boulon M5 x 20mm dans le petit trou sur le support de réservoir liquide de frein, avant de placer une rondelle M5 et un écrou à l'arrière (Photos 4 & 5) avant de serrer.
- Serrer tous les boulons de façon égale.

ISSUE 1 16/10/2013 (AR)