



**FITTING INSTRUCTIONS FOR FP0092BK FORK PROTECTORS
YAMAHA WR125X 2009-**



Please note that the way the kit is packed does not necessarily represent the way of mounting to the bike
Please note that in cases where kits are packed with rubber washers holding the components onto the bolt – *the rubber washers should be thrown away!*

YOU WILL NEED THE FOLLOWING TOOLS TO COMPLETE THIS JOB

Socket set to include two 10mm A/F sockets with wrenches.

- Fit one nut and washer onto the spindle-bar (either end).
- Feed spindle-bar with nut and washer through any bobbin (so nut goes into counter-bore) then place the larger spacer into the recess of bobbin (face with-out printing) with the angled facet away from bobbin.
- Feed assembly through front wheel spindle from left hand side of bike as you sit on it (as shown above left) the angled facet sits against fork upright.
- Place remaining spacer over exposed right hand end of spindle-bar so the counter-bore locates over the spindle nut.
- Place remaining bobbin over exposed end of spindle-bar and over spacer just fitted.
- Fit washer and nut from kit onto thread and tighten until both nuts are engaged in nylon and equal amounts protrude from either side. Do not over tighten – the nyloc nuts will hold it tight.

CONSUMER NOTICE

The catalogue description and any exhibition of samples are only broad indications of the Products and R&G may make design changes which do not diminish their performance or visual appeal and supplying them in such state shall conform to the order. The Buyer acknowledges no representation or warranty (other than as to title) has been given or will apply to the Products other than those in R&G's order or confirmation and the Buyer confirms it has chosen the Products as being of merchantable quality and suitable for its particular purposes. Where R&G fits the Products or undertakes other services it shall exercise reasonable skill and care and rectify any fault free of charge unless the workmanship has been disturbed. The Buyer is responsible for ensuring that the warranty on the motorcycle is not affected by the fitting of the Products. On return of any defective Products R&G shall at its option either supply a replacement or refund the purchase money but shall not be liable if the Products have been modified or used or maintained otherwise than in accordance with R&G's or manufacturer's instructions and good engineering practice or if the defect arises from accident or neglect. Other than identified above and subject to R&G not limiting its liability for causing death and personal injury, it shall not be liable for indirect or consequential loss and otherwise its liability shall be limited to the amounts paid by the Buyer for the Products or the fitting or service concerned. These terms do not affect the Buyer's statutory rights.

R&G RACING RETURNS POLICY (NON-FAULTY GOODS)

Returns must be pre-authorized (if not pre-authorized the return will be rejected). Goods may only be returned direct to us if they were purchased direct from us (customer must prove if necessary). Otherwise to be returned to original vendor. Goods must be in resellable condition, in the opinion of R&G Racing. All returns are subject to a 25% restocking and handling fee (25% of the gross value exc. P&P – at the prevailing price at time of purchase). The customer must pay any and all carriage charges. No returns of discontinued products, unless within 14 days of purchase. This policy does not affect your statutory rights and does not refer to faulty goods.

R&G Racing

Unit 5K, Blacknest Industrial Park, Blacknest Road, Alton, Hampshire, GU34 4PX

Tel: +44 (0)870 220 6380 Fax: +44 (0)1420 521101 www.rg-racing.com Email: info@rg-racing.com



FRANCE
INSTRUCTIONS DE MONTAGE DE LA PROTECTION DE FOURCHE FP0092BK
YAMAHA WR125X 2009-

Merci de noter que les pièces assemblées dans l'emballage ne sont pas nécessairement dans le sens du montage à réaliser sur la moto.

OUTILS NECESSAIRES

2 Clés de 10 mm.

- Placer les entretoises sur l'axe de roue avant (attention au sens de montage, Grande entretoise à facettes = côté Gauche et la petite entretoise= côté Droit)
- Pousser la barre R&G à travers les deux entretoises.
- Placer les tampons de chaque côté de l'axe.
- Glisser une rondelle de chaque côté et placer ensuite un écrou autobloquant de chaque côté.
- A l'aide de deux clés, serrez les deux écrous simultanément.
- Ne pas serrer trop fortement, en effet les écrous autobloquants vont garder le montage en place.