




FITTING INSTRUCTIONS FOR TP0009 FOOTBOARD SLIDERS
HONDA PCX 150



THIS KIT CONTAINS THE ITEMS PICTURED AND LABELLED BELOW.
DO NOT PROCEED UNTIL YOU ARE SURE ALL PARTS ARE PRESENT.

Please note that the way the kit is packed does not necessarily represent the way of mounting to the bike.

THE PARTS SHOWN MAY BE REPRESENTATIVE ONLY (FOR CLARITY OF INSTRUCTIONS ONLY)



LEFT SIDE

RIGHT SIDE




LEGEND

- ITEM 1 = MOUNTING PLATE LEFT SIDE (MP0024) (x1).
- ITEM 2 = SPACER (S0520) 19mm LONG (x2).
- ITEM 3 = M6x35mm LONG COUNTERSUNK BOLTS (x4).
- ITEM 4 = SPACER (S0521) 17mm LONG (x2).
- ITEM 5 = 10.5mm PUNCH TOOL (x1).
- ITEM 6 = M6 MARKING TOOL (x1).
- ITEM 7 = MOUNTING PLATE RIGHT SIDE (MP0025) (x1).
- ITEM 8 = SLIDER (SL0007) (x2).
- ITEM 9 = M5x15mm LONG COUNTERSUNK BOLTS (x6).
- ITEM 10 = M5 NYLOC NUT (x6).

Please note that in cases where kits are packed with rubber washers holding the components onto the bolt – *the rubber washers should be thrown away!*

TOOLS REQUIRED

- Set of metric Allen keys to include 3 & 4mm A/F sizes.
 - 10mm Socket and wrench.
 - Hammer/mallet.



PICTURE 1



PICTURE 2



PICTURE 3



PICTURE 4



PICTURE 5



PICTURE 6

FITTING INSTRUCTIONS (Left Side)

- Remove the original rubber foot plate by lifting a corner and gently pulling.
- Remove the two bolts that are now accessible, as arrowed in picture 1.
- Take the M6 making tool (item 6) that is in the kit and screw into one of these holes, ensuring the point is at the top, as shown in picture 2. Re-fit the original rubber foot plate and gently apply some pressure to the area around the marking tool. *This should give a small indentation to locate where to punch a hole through the rubber in order to fit the bolt.* Use the same process to locate the other bolt hole.
- With the rubber removed from the scooter, use the 10.5mm Punch Tool (item 5) supplied with the kit along with a hammer/mallet to create two holes where there is a mark, as shown in picture 3. *This should be done with a scrap piece of wood underneath the rubber and on a hard surface.*
- These holes then allow the top of the spacers to fit through in order for the bolt to tighten against, as shown in picture 4.
- Take the left side mounting plate (item 1) and fit the slider (item 8) using three of the M5 countersunk bolts (item 9). Fit the bolts through the slider and screw into the mounting plate and tighten, before adding a M6 nyloc nut (item 10) to the exposed thread of each bolt, as shown in picture 5.
- On the scooter, position the 19mm long spacer (item 2) in the front bolt hole recess (with the 10mm diameter boss facing upwards) and the 17mm long spacer (item 4) on the rear bolt hole recess (again, with the 10mm diameter boss facing upwards), as shown in picture 6.
- Re-fit the original foot plate rubber, ensuring that the tops of the two spacers fit through the holes that have just been punched in the rubber.
- Offer the R&G footboard slider assembly into position and insert the M6 x 35mm long countersunk bolts (item 3) into both spacers, sandwiching the rubber, before tightening evenly.
- To fit the right side, follow the same procedure as above.

CONSUMER NOTICE

The catalogue description and any exhibition of samples are only broad indications of the Products and R&G may make design changes which do not diminish their performance or visual appeal and supplying them in such state shall conform to the order. The Buyer acknowledges no representation or warranty (other than as to title) has been given or will apply to the Products other than those in R&G's order or confirmation and the Buyer confirms it has chosen the Products as being of merchantable quality and suitable for its



particular purposes. Where R&G fits the Products or undertakes other services it shall exercise reasonable skill and care and rectify any fault free of charge unless the workmanship has been disturbed. The Buyer is responsible for ensuring that the warranty on the motorcycle is not affected by the fitting of the Products. On return of any defective Products R&G shall at its option either supply a replacement or refund the purchase money but shall not be liable if the Products have been modified or used or maintained otherwise than in accordance with R&G's or manufacturer's instructions and good engineering practice or if the defect arises from accident or neglect. Other than identified above and subject to R&G not limiting its liability for causing death and personal injury, it shall not be liable for indirect or consequential loss and otherwise its liability shall be limited to the amounts paid by the Buyer for the Products or the fitting or service concerned. These terms do not affect the Buyer's statutory rights.

R&G RACING RETURNS POLICY (NON-FAULTY GOODS)

Returns must be pre-authorized (if not pre-authorized the return will be rejected). Goods may only be returned direct to us if they were purchased direct from us (customer must prove if necessary). Otherwise to be returned to original vendor. Goods must be in re-sellable condition, in the opinion of R&G Racing. All returns are subject to a 25% restocking and handling fee (25% of the gross value exc. P&P – at the prevailing price at time of purchase). The customer must pay any and all carriage charges. No returns of discontinued products, unless within 14 days of purchase. This policy does not affect your statutory rights and does not refer to faulty goods.




Instructions de montage pour TP0009 Sliders de marche pied
HONDA PCX 150



LE KIT CONTIENT LES ARTICLES EXPOSES CI-DESSOUS, VERIFIER QUE TOUTES LES PIECES SOIENT PRESENTES AVANT DE PROCEDER AU MONTAGE.

LA FAÇON DONT LE KIT EST EMBALLE NE CORRESPOND PAS FORCEMENT A LA FAÇON DE MONTER LES PIECES SUR LA MOTO.

LES PIECES PRESENTEES PEUVENT N'ETRE QUE REPRESENTATIVES, AFIN DE FACILITER ET CLARIFIER LES INSTRUCTIONS DE MONTAGE.





LEGENDE

ARTICLE 1 = Plaque de montage coté gauche (MP0024) (x1).

ARTICLE 2 = Entretoise (S0520) 19mm de long (x2).

ARTICLE 3 = M6x35mm Boulon à tête fraisée (x4).

ARTICLE 4 = Entretoise (S0521) 17mm de long (x2).

ARTICLE 5 = 10.5mm Poinçon (x1).

ARTICLE 6 = M6 Outil de marquage (x1).

ARTICLE 7 = Plaque de montage coté droit (MP0025) (x1).

ARTICLE 8 = SLIDER (SL0007) (x2).

ARTICLE 9 = M5x15mm Boulon à tête fraisée (x6).

ARTICLE 10 = M5 Ecrou en nyloc (x6).

Notez que si les kits sont emballés avec des rondelles en caoutchouc servant à tenir les composants, *ces rondelles doivent être jetées.*

Outils requis

- Clés Allen 3 et 4 mm.
- Clé de 10mm.
- Maillet.




PHOTO 1



PHOTO 2



PHOTO 3



PHOTO 4



PHOTO 5



PHOTO 6

Instructions de montage (Coté gauche)

- Enlever la plaque en caoutchouc du repose pied d'origine en soulevant un coin et en tirant doucement.
- Enlevez les 2 boulons qui à présent sont accessible (Photo 1).
- Prendre l'outil de marquage M6 (Article 6) qui est dans le kit puis visser dans un des trous, en vous Assurant que le point est en haut (Photo 2). Remontez la plaque d'origine en caoutchouc du marche pied et émettre une petite pression sur l'espace entourant l'outil de marquage. *Cela va créer un léger renforcement afin de localiser l'endroit où faire un trou à travers le caoutchouc pour passer le boulon.* Répéter le même process pour localiser l'autre trou.
- Avec le caoutchouc retiré du scooter, utilisez l'outil de perforation 10,5 mm (article 5) fourni avec le kit et un marteau / maillet pour créer deux trous où il y a une marque, comme le montre la photo 3. Il est bien de faire cela avec un morceau de bois sous le caoutchouc et sur une surface rigide.
- Ces trous permettrons par la suite aux entretoises de passer à travers pour que le boulon soit resserré (Photo 4).
- Prendre le support de montage coté gauche (Article 1) et installer le slider (Article 8) en utilisant 3 des boulons M5 à tête fraisée (Article 9). Passer les boulons à travers le slider et visser dans le support de plaque puis bloquer, avant d'ajouter un écrou en Nyloc M6 (Article 10) à l'extrémité opposée de chaque boulon (Photo 5).
- Positionner l'entretoise de 19mm de long sur le scooter (Article 2) sur le creux du trou de boulon avant et la l'entretoise de 17mm de long (Article 4) sur le creux arrière du trou de boulon (une nouvelle fois, avec un patron de 10mm de diamètre (Photo 6).
- Remettre le caoutchouc d'origine du repose pied, en vous Assurant que le dessus des 2 entretoises aillent à travers les trous qui viennent juste d'être faits dans le caoutchouc.
- Mettre le repose pied R&G couissant en position et insérer les boulons à tête fraisée M6 x 35mm de long (article 3) dans les deux entretoises, prenant en sandwich le caoutchouc, avant de serrer uniformément.
- Pour le coté droit, répéter la procédure.

R&G Racing

Unit 1, Shelley's Lane, East Worldham, Alton, Hampshire, GU34 3AQ

Tel: +44 (0)1420 89007 Fax: +44 (0)1420 87301 www.rg-racing.com Email: info@rg-racing.com



CONSUMER NOTICE

The catalogue description and any exhibition of samples are only broad indications of the Products and R&G may make design changes which do not diminish their performance or visual appeal and supplying them in such state shall conform to the order. The Buyer acknowledges no representation or warranty (other than as to title) has been given or will apply to the Products other than those in R&G's order or confirmation and the Buyer confirms it has chosen the Products as being of merchantable quality and suitable for its particular purposes. Where R&G fits the Products or undertakes other services it shall exercise reasonable skill and care and rectify any fault free of charge unless the workmanship has been disturbed. The Buyer is responsible for ensuring that the warranty on the motorcycle is not affected by the fitting of the Products. On return of any defective Products R&G shall at its option either supply a replacement or refund the purchase money but shall not be liable if the Products have been modified or used or maintained otherwise than in accordance with R&G's or manufacturer's instructions and good engineering practice or if the defect arises from accident or neglect. Other than identified above and subject to R&G not limiting its liability for causing death and personal injury, it shall not be liable for indirect or consequential loss and otherwise its liability shall be limited to the amounts paid by the Buyer for the Products or the fitting or service concerned. These terms do not affect the Buyer's statutory rights.

R&G RACING RETURNS POLICY (NON-FAULTY GOODS)

Returns must be pre-authorised (if not pre-authorised the return will be rejected). Goods may only be returned direct to us if they were purchased direct from us (customer must prove if necessary). Otherwise to be returned to original vendor. Goods must be in re-sellable condition, in the opinion of R&G Racing. All returns are subject to a 25% restocking and handling fee (25% of the gross value exc. P&P – at the prevailing price at time of purchase). The customer must pay any and all carriage charges. No returns of discontinued products, unless within 14 days of purchase. This policy does not affect your statutory rights and does not refer to faulty goods.